



**PUSH BUTTON STATION TYPE "OZA"**



OZA - 271

OZA - 471

OZA - 671

OZA - 871

OZA - 1071

OZA - 1271

**HOIST PUSH BUTTON SERIES WITH EMERGENCY TYPE "OZA"**



OZA - 2713

OZA - 4713

OZA - 6713

OZA - 8713

OZA - 10713

OZA - 12713

**HOIST PUSH BUTTON SERIES TYPE "OZC"**



OZ 61C

OZ 62C

OZ 63C

OZ 64C

OZ 65C

OZC - 66C

OZC - 61E

OZC - 61D


Two Speed Element



Push Button Stations are available to fit a wide variety of applications from the simplest one motion hoist to three-motion cranes with multiple switches and accessories.

**HOUSING (PLASTIC) (LIGHT)**  
White + Black

- BX1
- BX2
- BX3
- BX4
- BX5
- BX6



**HOUSING (heavy) black + grey**

- BX1
- BX2
- BX3



**WIRELESS REMOTE CONTROL**



F-21-E1B-TX

**PUSH BUTTON STATION TYPE "OZ XAL"**



OZ XAL D 101



OZ XAL D 164 / 174



OZ XAL D 213



OZ XAL D 324

**COB SERIES**

- COB 61
- COB 62
- COB 63
- COB 64
- COB 65



**COB SERIES (WITH ON/OFF)**

- COB 61A
- COB 62A
- COB 63A
- COB 64A
- COB 65A

