



INDUCTIVE SENSORS (FLUSH / NON FLUSH)

INDUCTIVE SENSORS TYPE "OZI" | M - 5 | M - 6 | M - 8

| | | | | | | |
|-----------|-----|----------|------------------------------|------------------------------|------------------------------|--|
| FLUSH | NPN | NO NC | OZI-5 - FNNO OZI-5 - FNNC | OZI-6 - FNNO OZI-6 - FNNC | OZI-8 - FNNO OZI-8 - FNNC | |
| | PNP | NO NC | OZI-5 - FPNO OZI-5 - FPNC | OZI-6 - FPNO OZI-6 - FPNC | OZI-8 - FPNO OZI-8 - FPNC | |
| | AC | NO NC | OZI-5 - FANO OZI-5 - FANC | OZI-6 - FANO OZI-6 - FANC | OZI-8 - FANO OZI-8 - FANC | |
| NON FLUSH | NPN | NO NC | OZI-5 - NNO OZI-5 - NNC | OZI-6 - NNO OZI-6 - NNC | OZI-8 - NNO OZI-8 - NNC | |
| | PNP | NO NC | OZI-5 - PNO OZI-5 - PNC | OZI-6 - PNO OZI-6 - PNC | OZI-8 - PNO OZI-8 - PNC | |
| | AC | NO NC | OZI-5 - ANO OZI-5 - ANC | OZI-6 - ANO OZI-6 - ANC | OZI-8 - ANO OZI-8 - ANC | |

INDUCTIVE SENSORS TYPE "OZI" | M - 12 | M - 18 | M - 30

| | | | | | | |
|-----------|-----|-------------------|---|---|---|--|
| FLUSH | NPN | NO NC NO+NC | OZI-12 - FNNO OZI-12 - FNNC OZI-12 - FN NO+NC | OZI-18 - FNNO OZI-18 - FNNC OZI-18 - FN NO+NC | OZI-30 - FNNO OZI-30 - FNNC OZI-30 - FN NO+NC | |
| | PNP | NO NC NO+NC | OZI-12 - FPNO OZI-12 - FPNC OZI-12 - FP NO+NC | OZI-18 - FPNO OZI-18 - FPNC OZI-18 - FP NO+NC | OZI-30 - FPNO OZI-30 - FPNC OZI-30 - FP NO+NC | |
| | AC | NO NC NO+NC | OZI-12 - FANO OZI-12 - FANC | OZI-18 - FANO OZI-18 - FANC | OZI-30 - FANO OZI-30 - FANC OZI-30 - FA NO+NC | |
| NON FLUSH | NPN | NO NC | OZI-12 - NNO OZI-12 - NNC | OZI-18 - NNO OZI-18 - NNC | OZI-30 - NNO OZI-30 - NNC | |
| | PNP | NO NC | OZI-12 - PNO OZI-12 - PNC | OZI-18 - PNO OZI-18 - PNC | OZI-30 - PNO OZI-30 - PNC | |
| | AC | NO NC | OZI-12 - ANO OZI-12 - ANC | OZI-18 - ANO OZI-18 - ANC | OZI-30 - ANO OZI-30 - ANC | |

INDUCTIVE SENSORS TYPE "OZI" | M - 18 | M - 30

| | | | | |
|-----|----|--------------|--------------|--|
| NPN | NO | OZC-18 - NNO | OZC-30 - NNO | |
| | NC | OZC-18 - NNC | OZC-30 - NNC | |
| PNP | NO | OZC-18 - PNO | OZC-30 - PNO | |
| | NC | OZC-18 - PNC | OZC-30 - PNC | |
| AC | NO | OZC-18 - ANO | OZC-30 - ANO | |
| | NC | OZC-18 - ANC | OZC-30 - ANC | |



COLOR MARK SENSORS

COLOR MARK SENSOR

- KS - C2G
- KS - C2R
- KS - C2W
- KS - C2RG
- KS - C2WB
- KS - W22



COLOR MARK SENSOR

- BZJ - 211
- BZJ - 311
- BZJ - 411



PHOTO SENSOR - M 18

- OZG18 - NPN NO
- OZG18 - PNP NO
- OZG18 - AC NO
- OZG18 - AC NC
- OZG18 - NPN - NO+NC
- OZG18 - PNP - NO+NC



PHOTO SENSOR (CUBICAL)

- OZ E3JK R 4M1 (with reflector)
- OZ E3JK R 4M2 (with reflector)
- OZ E3JK DS 30M1
- OZ E3JK DS 30M2



SQUARE TYPE SENSORS

SNO4 (18 X 18 X 36)

- NPN - NO
- PNP - NO
- AC - NO
- AC - NC



OZ - TL N15 (35 X 35 X 52)

- OZ - TL-N15 - MF1 - PNP NO
- OZ - TL-N15 - ME1 - NPN NO



OZ TL TYPE

- OZ TL - W5MP1 - PNP-NO
- OZ TL - W5MP2 - NPN-NO



FP TYPE

- FP-18-5DP - PNP NO
- FP-18-5DN - NPN NO



OZ LM TYPE

- OZ LM37 - 3020 - PC
- OZ LM37 - 3020 - NC



OZ E3S TYPE

- OZ E3S-GS30P1 - PNP NO
- OZ E3S-GS30N1 - NPN NO



PROXIMITY SENSOR – PLUG IN TYPE



■ M -12



■ M -18



■ M -30

PROXY LEAD (WITH LED /WITHOUT LED)

*available in 3 wire and 4 wire



■ L -TYPE




■ L -TYPE




■ STRAIGHT

PHOTO CELL (DAY/LIGHT) SENSORS



■ SK – AS 10



■ SK – AS 15



■ SK – AS C 2210